

MODEL "B" Series



Single Channel
Inductive Loop Vehicle Detectors
With Built-In Diagnostics Utilizing Non-Volatile Memory

11 Pin Rear "Amphenol" Connector



10 Pin Rear "MS" Connector



FEATURES & BENEFITS:

- ä Advanced Diagnostics: Low Voltage, Open Loop, and Shorted Loop Conditions.
- ä Non-Volatile Memory insures loop diagnostics are not lost when power is removed.
- ä Automatic Reset Internal Fuse (24 VAC versions ONLY), provides fuse & circuit protection when incorrect voltage is applied.
- ä Detect Memory helps prevent detection drops during short power interruptions.
- ä Sensitivity Boost, for gate operation where high profile vehicles might be encountered.
- ä 2 Second Call Delay.
- ä Dual Programmable relays offer selectable modes of operation:
 - ã Output A:
 - True Presence (Infinite)
 - Limited Presence
 - ã Output B:
 - Presence (Duplicates "Output A")
 - Pulse on Entry
 - Pulse on Exit
- ä Fail-Safe and Fail-Secure versions available.
- ä 4 loop frequencies selectable from the front panel. LED's provide front panel view of frequency selection.
- ä 8 levels of sensitivity.
- ä Super bright LED's provide separate Power, Detect, & Loop Fail Indications.
- ä 11 pin Rear "Amphenol" and 10 pin rear "MS" connector versions available.
- ä Configurations available: 24 VAC, 120 VAC, 240 VAC, 12 VDC, & 24 VDC.

Manufactured By:

Reno A & E
4655 Aircenter Circle
Reno, Nevada 89502 USA
Tel: (702) 826-2020
Fax: (702) 826-9191
E-mail: sales@renoae.com
Internet: www.renoae.com

Distributed By:

Specifications:

Loop Frequency: Four frequencies (normally in the range of 20 to 100 kilohertz) are switch selectable from the front panel. Four super bright LED's indicate frequency setting.

Reset: The detector can be manually reset by a front panel push button switch or interrupting power.

Sensitivity: Vehicle detection results when a negative change in loop inductance ($-\Delta L/L$) exceeds the sensitivity setting. Eight detection sensitivity levels are internally DIP switch selectable. (See Tables, "Sensitivity").

Sensitivity Boost: An internal switch setting may be turned ON to increase sensitivity ONLY during the DETECT period. When a vehicle enters the loop, the detector sensitivity is boosted to a higher level than the vacant loop setting. The boosted sensitivity remains throughout the DETECT period. When the vehicle leaves the loop, the sensitivity returns to the vacant loop setting. This feature helps prevent dropouts during the passage of high bed vehicles and is particularly useful in sliding gate situations.

Relay "A" Modes: Two presence hold times are selectable for Relay A with an internal switch, "TruePresence™" and "Limited Presence". Both modes output a "Call" when a vehicle is present in the loop. TruePresence™ will hold the Call for as long as the vehicle is present and power is not removed or reset applied. Limited presence will typically hold the Call output for about one to three hours. The TruePresence™ time applies only for normal size automobiles and trucks and for normal size loops (approx. 12 sq. ft. to 120 sq. ft.).

Relay "B" Modes: Two modes of operation are selectable for Relay B with an internal switch, Presence or Pulse. When in the presence mode, the presence hold time is the same as Output A. When in the pulse mode, the 250 millisecond pulse can be selected as either pulse on entry (when a vehicle enters the loop) or pulse on exit (when a vehicle exits the loop). Relay B is always a Fail Secure Output.

Call Delay: A two second delay of Outputs A & B can be activated by an internal switch. Output delay is the time the detector outputs are delayed after a vehicle first enters the loop detection area and is indicated by the front panel "DET" LED flashing at 4 Hz with a 50% duty cycle. If the 2 second output delay feature is activated, the output relays will only be turned on after 2 seconds has passed with a vehicle continuously present in the loop detection area. If a vehicle leaves the loop detection area during the 2 second delay interval, detection is aborted and the next vehicle entering the loop detection area will initiate a new full 2 second delay interval.

Output "Call" Memory: When power is removed for 2 seconds or less, the detector automatically "remembers" if a vehicle was present over the loop. When power is restored, the detector will continue to output a Call until the vehicle leaves the loop. (Power loss or dips of 2 seconds or less will not drop the Call).

Power Status Indicator: A green super high intensity light emitting diode (LED) indicates power status during normal detector operation. When the green (PWR) LED is ON the power to the detector is normal. When power drops approx. 20% from nominal, the green LED turns OFF and the detector remains operational. When power drops approx. 25% from nominal, the green LED is OFF and the "line" voltage is not sufficient to operate the detector.

Detect Status Indicator: The red (DET) LED is steady ON while a vehicle is being detected. The (DET) LED will flash at a 4 Hz rate with a 50% duty cycle while timing out the 2 Second Call Delay.

Loop Fail Monitor Indicator: If the total inductance of the detector input network goes out of the range specified for the detector or suddenly changes more than +/-32% the detector will enter fail mode. The red "FAIL" LED will either begin flashing with a 50% duty cycle once per second for a shorted loop condition or will be ON continuously for an open loop condition. These indicator conditions will continue until the inductance returns to its previous value at which time the detector output will automatically resume normal operation and the red "FAIL" LED will turn OFF. See *Non-Volatile "Loop Fail" Memory Status*. [The detector input network, consists of the loop or loops plus the feeder cable (lead-in or home run) up to the connector on the detector].

Non-Volatile "Loop Fail" Memory Status: To review the detectors last "loop fail" condition, **PRESS & HOLD** the frequency button until the FAIL light begins to flash (3 seconds) - then release. Note the detector remains in full operation during interrogation. The red "FAIL" LED will either be **OFF (no loop problems occurred)**, **FLASHING (shorted loop condition occurred)** or **STEADY ON (open loop condition occurred)**. After 15 seconds the non-volatile memory is cleared and reset. (Note, power loss and/or pressing the reset button does not clear stored memory).

Fail Safe Operation: When the loop fails or power is removed, continuity exists between Common & N.O. for Relay A. Continuity exists between Common & N.C. for Relay B.

Fail Secure Operation: When the loop fails or power is removed, continuity exists between Common & N.C. for both relays A & B.

Self Tuning: Automatically tunes to loop within 2 seconds after application of power or reset. 30 seconds of operation is required before full sensitivity and presence time is reached following application of power or a reset.

Environmental Tracking: Fully self-compensating for environmental changes and loop drift over the full temperature range and the entire loop inductance range.

Loop Inductance Range: 20 to 1000 microhenries with Q factor of 5 or greater.

Loop Input: Transformer isolated. The minimum capacitance added by the detector is 0.068 microfarads.

Grounded Loop Operation: The loop isolation transformer allows operation with poor quality loops (which may include a single point short, or leakage, to ground).

Lightning Protection: The detector can tolerate, without damage, a 10 microfarad capacitor charged to 1,000 volts being discharged directly into the loop input terminals, or a 10 microfarad capacitor charged to 2,000 volts being charged between either loop terminal and earth ground.

Internal Circuitry Isolation: All internal electronic circuitry is isolated from all external circuitry. Power is isolated by means of the power transformer. The loop is isolated by means of the loop isolation transformer. The outputs are isolated by means of the output relays.

Automatic Reset Internal Fuse: When 120 VAC is applied to 24 VAC models, the automatic internal fuse will open. The fuse will automatically reset when power is removed for 3 seconds. Source voltage should be verified before reinstalling.

Relay Rating(s): The relay contacts are rated for 6 Amp max., 150 VDC max., 300 VAC max and 180 Watts max. switched power.

Ruggedized Construction: The 11 pin "Amphenol" type enclosures are high temperature rated lexan plastic. The 10 pin "MS" type enclosures are aluminum with a durable fused polyester coating. Printed circuit boards are double sided 2 oz./copper with plated through holes.

Operating Temperature: -40°F to + 180°F. Meets or exceeds NEMA specifications.

Power(s):
 18 to 32 VAC, 50/60 Hz., 4.0 Watts max.
 89 to 135 VAC, 50/60 Hz., 4.0 Watts max.
 176 to 288 VAC., 50/60 Hz., 4.0 Watts max.
 10 to 16 VDC, 80 milliamps max.
 20 to 34 VDC, 50 milliamps max.

Fuse(s):
 24 VAC power: 120 milliamp., Polymeric
 120 VAC power: 3/8 amp., Slo-Blo.
 240 VAC power: 3/8 amp., Slo-Blo.
 12 VDC power: Current limited.
 24 VDC power: Current limited.

Size(s):
 11 Pin "Amphenol" Connector Type: 1.75 inches (4.45 cm.) Wide x 3.00 inches (7.62 cm.) High x 5.00 inches (12.70 cm.) Deep, including rear connector.
 10 Pin "MS" Connector Type: 1.60 inches (4.06 cm.) Wide x 2.90 inches (7.37 cm.) High x 5.66 inches (14.38cm.) Deep, including rear connector.

Weight(s):
 11 Pin "Amphenol" Connector Type: Approx. 8.1 oz. (229.64 gm.).
 10 Pin "MS" Connector Type: Approx. 12.8 oz. (362.88 gm.).
Connector(s): Rear mount
 11 Pin male "Amphenol" connector (86CP11).

Tables:

SENSITIVITY			
Sens.	-ΔL/L	Sens.	-ΔL/L
0	1.28%	4	0.08%
1	0.64%	5	0.04%
2	0.32%	6	0.02%
3	0.16%	7	0.01%

PIN ASSIGNMENTS

11 Pin "Amphenol" Connector:

Pin	Function
1	Power, Hot or (+)
2	Power, Neutral or (-)
3	Output B, Normally Open (N.O.)
4	No Connection
5	Output A, Common
6	Output A, Normally Open (N.O.)
7	Loop
8	Loop
9	Output B, Common
10	Output A, Normally Closed (N.C.)
11	Output B, Normally Closed (N.C.)

11 PIN MODELS & CONFIGURATIONS:

Model	Connector	Voltage	Operation
B-3	11 Pin "Amphenol"	120 VAC	Fail Safe
B-3(S)	11 Pin "Amphenol"	120 VAC	Fail Secure
B-7	11 Pin "Amphenol"	24 VAC	Fail Safe
B-7(S)	11 Pin "Amphenol"	24 VAC	Fail Secure
B-8	11 Pin "Amphenol"	240 VAC	Fail Safe
B-8(S)	11 Pin "Amphenol"	240 VAC	Fail Secure
B-23	11 Pin "Amphenol"	12 VDC	Fail Safe
B-23(S)	11 Pin "Amphenol"	12 VDC	Fail Secure
B-24	11 Pin "Amphenol"	24 VDC	Fail Safe
B-24(S)	11 Pin "Amphenol"	24 VDC	Fail Secure

10 Pin "MS" Connector:

Pin	Function
A	Power, Neutral or (-)
B	Output A, Normally Open (N.O.)
C	Power, Hot or (+)
D	Loop
E	Loop
F	Output A, Common
G	Output A, Normally Closed (N.C.)
H	Chassis Ground
I	Output B, Common
J	Output B, Normally Open (N.O.)

10 PIN MODELS & CONFIGURATIONS:

Model	Connector	Voltage	Operation
B-1	10 Pin "MS"	120 VAC	Fail Safe
B-1(S)	10 Pin "MS"	120 VAC	Fail Secure
B-22	10 Pin "MS"	24 VAC	Fail Safe
B-22(S)	10 Pin "MS"	24 VAC	Fail Secure
B-35	10 Pin "MS"	240 VAC	Fail Safe
B-35(S)	10 Pin "MS"	240 VAC	Fail Secure

Notes:

a Relay contacts are shown with power applied, loop(s) connected, and no vehicles present.

FACTORY DEFAULT SETTINGS:

Sensitivity Level: Level 3
 Output Configurations: Relay A = TruePres. (Infinite)
 Relay B = Pulse on Entry
 Sensitivity Boost: OFF
 2-Second Call Delay: OFF

Notes: 1. "Detect" Memory is ALWAYS ON. There is no switch setting for this feature.
 2. Please specify correct model number for **Fail-Safe** or **Fail-Secure** when ordering.



Engineering Excellence!