

INSTALLATION INSTRUCTIONS: ETP-WM/E & ETP-WM/E24 WALL MOUNTS

The Model ETP-WM/E and ETP-WM/E24 Wall Mount units are designed to house the Talk-A-Phone Blue Light/Strobe and a Talk-A-Phone 400-series ADA compliant hands-free Emergency Phone.

On the ETP-WM/E, the blue light/strobe requires 120VAC, 25W maximum. On the ETP-WM/E24, 18W maximum is required. The strobe connects to auxiliary port number 2 of the Emergency Phone. The Emergency Phone connects via its RJ-11 connector to a standard phone line or PBX extension. The Emergency Phone does not connect to any power source other than the telephone line.

To install the Wall Mount, after site preparation (including telephone line and provision of power for the Blue Light/Strobe) follow these steps.

- 1) The Wall Mount is held to the wall with 4 #10 screws. Install two #10 screws in order to hold the top section to the wall. Note that the screws should be located so that the Wall Mount will be at the desired height and in the correct position to receive any conduit connections.
- 2) Electric power and the telephone line can be brought into the unit in one of two ways.
 - a) There are two large openings in the back of the unit to allow the unit to be mounted over a flush mounted standard electrical outlet box and/or flush mounted telephone connector box.
 - b) There are two conduit openings available on the bottom of the unit for connection of power and/or telephone line. (**Note:** Power and telephone lines cannot be run in same conduit.)
- 3) Remove the cap lid from the Wall Mount by removing the four #10 spanner security screws located on the side of the unit. DO NOT remove the Lexan shield from the unit. Mount the unit on the wall using the two keyholes on the top rear of the unit to the two screws mounted to the wall in step 1.
- 4) Install two additional #10 screws of the appropriate type in the holes in the lower rear of the unit. Tighten all four screws.
- 5) Install conduit to hole(s) in bottom of unit, if this method is being used (see step 2), and bring power line and/or telephone line to inside of unit.
- 6) To connect the Blue Light/Strobe, connect the power cord to the power source, and connect the dry contact control line to the orange and black wires (auxiliary output #2) extending from the Emergency Phone. For 120VAC operation, the attached plugs may be used or cut off for hard-wiring. For 24VDC operation, see the wiring diagram below.
- 7) Connect the RJ-11 plug extending from the Emergency Phone to a phone line connection box.
- 8) Mount the Emergency Phone into the recessed opening of the Wall Mount using the 6 #10-24 security screws provided.

INSTALLATION INSTRUCTIONS: ETP-WM/E & ETP-WM/E24 WALL MOUNTS

